

Broil King®

ASSEMBLY MANUAL & PARTS LIST - MANUEL DE MONTAGE & LISTE DE PIÈCES - MANUAL DE ARMADO Y LISTA DE PARTES



Broil King

PORTA CHEF AT220
9108-54



RETAIN FOR FUTURE REFERENCE - VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE - CONSERVER PARA FUTURAS CONSULTAS

Onward
MANUFACTURING COMPANY LIMITED
SINCE 1906
585 KUMPF DRIVE
WATERLOO, ONTARIO, CANADA
N2V 1K3



info@omcbbq.com
1-800-265-2150

10084-E26 REV A 12/16



1




2









3




4




5




6





7





9





PARTS LIST / LISTE DES PIECES / TEILELISTE

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	DESCRIPTION	9108-54
1	10909-E221R	CASTING BOTTOM	FOND DU FOYER	CUERPO INFERIOR	1
2	10473-E201	CASTING TOP	COUVERCLE DU GRIL	CUERPO SUPERIOR	1
3	10081-BK530	NAMEPLATE	PLAQUE D'IDENTIFICATION	PLACA CON NOMBRE	1
4	10958-E200A	TOP CASTING INSERT	PANNEAU DE COUVERCLE	INSERTO DE CUERPO	1
5	10571-5	HEAT INDICATOR	INDICATEUR DE CHALEUR	INDICADOR DE TEMPERATURA	1
6	Y-11980	PIN	GOUPILLE	CLAVIJA	4
7	S21233	HITCH PIN CLIP	ATTACHE DE CHEVILLE	GANCHO PARA EL REMOLQUE	4
9	10225-T206	GRID	GRILLE	REJILLA	1
10	32001-904	FLAV-R-WAVE™	FLAV-R-WAVE™	FLAV-R-WAVE™	1
11	10225-T247	WARMING RACK	GRILLE	REJILLA	1
15	32900-144	BURNER	BRÛLEUR	QUEMADOR	2
17	10342-244	IGNITOR	ALLUMAGE	ENCENDEDOR ELECTRÓNICO	1
18	10342-E12	ELECTRODE	ELECTRODE	ELECTRODO	1
19	10320-264A	COLLECTOR BOX	BOÎTE DE COLLECTEUR	CAJA RECOLECTORA	1
21	39001-103	CONTROL ASSEMBLY	SOUPAPE	MECANISMO DE CONTROL	1
21A	10110-89	GAS TRAIN	TUBE DE GAZ	TUBO DE GAS	1
21B	30830-304A	REGULATOR	REGULATEUR	REGULADOR	1
22	30114-34	HOSE	TUYAU	MANGUERA	1
23	10472-K431	CONTROL KNOB	BOUTON DE CONTROLE	PERILLA DE CONTROL	2
24	39830-304	VALVE BRACKET	SUPPORT DE SOUPAPE	SOPORTE DE VÁLVULA	1
25	Y-29308	VALVE NUT	ÉCROU POUR VANNE	TUERCA DE VÁLVULA	2
29	35651-E251A	SHELF	PLANCHETTE	ESTANTE	1
30	33412-348	VALVE TRAY	PLATEAU DE VALVE	BANDEJA DE VÁLVULA	1
31	31001-011A	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	1
32	31001-013A	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	1
33	31403-E271L	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	1
34	31403-E271R	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	1
35	31403-E261R	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	2
36	31403-E261	LEG ASSEMBLY	JAMBE ASSEMBLÉE	ASAMBLEA DE PIERNAS	2
37	34100-904	LID PIN	PIN COUVERCLE	PIN TAPA	2
40	35002-301	TANK BASE	TABLETTE INFERIEUR	BASE - TANQUE	1
41	35031-301	LEG BRACE	ENTRETOISE	ABRAZADERA	1
42	S21422	PUSH NUT	POUSSE ECROU	TUERCA DE COMPRESIÓN	2
43	31430-978A	PIVOT ASSEMBLY	ENSEMBLE PIVOTE	ENSAMBLE DE PIVOTE	2
44	S21421	PUSH NUT	POUSSE ECROU	TUERCA DE COMPRESIÓN	2
47	37500-378A	LEG CLIP	CLIP DE JAMBES	CLIP DE PIERNA	4
50	33410-348	TOOL HOOK	CROCHET D'OUTILS	GANCHO DE HERRAMIENTAS	1
51	33411-348	CORNER	BORDER	ESQUINA	4
56	10892-751	WHEEL	ROUE	RUEDA	2
58	34000-336	BEZEL	MONTURE	PANEL	2
70	Y-12228	INNER AXLE BUSHING	COL	COJINETE	2
71	Y-12227	OUTER AXLE BUSHING	COL	COJINETE	2
73	22002-248	HUB CAP	ENJOLIVEUR DE ROUE	EMBELLECEDOR DE LA RUEDA	2
75	21106-13	HANDLE	POIGNÉE	MANGO	1
78	31422-348	LEG HANDLE	POIGNÉE DES JAMBES	MANGO DE PIERNA	1
81	Y-12310	SCREW 1/4-20 X 3/4	VIS 1/4-20 X 3/4	TORNILLO 1/4-20 X 3/4	6
83	Y-12855	SCREW 1/4-20 X 3/8	VIS 1/4-20 X 3/8	TORNILLO 1/4-20 X 3/8	2
86	Y-12865	SCREW 1/4-20 X 1/2	VIS 1/4-20 X 1/2	TORNILLO 1/4-20 X 1/2	2
87	Y-11793	NUT 1/4-20	ECROU 1/4-20	TUERCA 1/4-20	6
96	S21125	SCREW #8 X 3/8	VIS #8 X 3/8	TORNILLO #8 X 3/8	17
98	S21124	SCREW #8 X 1/2	VIS #8 X 1/2	TORNILLO #8 X 1/2	4
102	31021-508	LEG SLIDE	DIAPOSITIVE	DIAPPOSITIVA DE PIERNA	2
103	35001-301	TANK BRACKET	SUPPORT DU RESERVOIR	SOPORTE - TANQUE LP	1
123	32041-302	HEAT SHIELD	BOUCLIER	PROTEGER	1
161	Y-29302	SCREW #10-24 X 1	VIS #10-24 X 1	TORNILLO #10-24 X 1	4
166	Y-11979	BOLT 1/4-20 X 3/8	BOULON 1/4-20 X 3/4	PERNO - 1/4-20 X 3/4	6

